

# MIGEL



برس  
صاف کننده مو

GHS 60

English

فارسی

مشتری گرامی ضمن تشکر از حسن سلیقه و اعتماد شما به برند میگل امیدواریم از کار با این دستگاه لذت ببرید.

## اطلاعات برقی دستگاه

مدل	ولتاژ	فرکانس	توان
GHS 60	۲۲۰-۲۴۰ ولت	۵۰/۶۰ هرتز	۵۰ وات

## دستور العمل های ایمنی مهم

**هشدار:** از این دستگاه در نزدیکی وان حمام، دوش حمام، سینک دستشویی، یا سایر ظروف حاوی آب استفاده نکنید.

- در صورتیکه از دستگاه در حمام استفاده می کنید، پس از استفاده دوشاخه را از پریز برق جدا کرده و دستگاه را در مکانی به دور از دسترس آب انبارش و نگهداری نمایید.
- هرگز دستگاه را درون آب یا هر مایع دیگری فرو نبرید.
- در صورت آسیب دیدگی کابل برق دستگاه، برای جلوگیری از خطر، کابل حتماً بایستی توسط تولید کننده، واحد خدمات پس از فروش میگل، یا افراد دارای صلاحیت تعویض گردد.
- در صورت افتادن (سقوط) دستگاه بر روی زمین یا مشاهده هر نوع آسیب دیدگی، از دستگاه استفاده نکنید.
- زمانیکه دوشاخه دستگاه به پریز برق متصل می باشد، یا در صورت روشن بودن دستگاه، آن را بدون مراقبت رها نکنید.
- در صورتیکه هنگام استفاده از دستگاه با مشکل مواجه شدید، بلافاصله دوشاخه دستگاه را از پریز برق جدا نمایید.
- از هیچ لوازم جانبی دیگری غیر از مواردی که تولید کننده آنها را توصیه کرده است، استفاده نکنید.
- پیش از تمیز کاری دستگاه، و همچنین پس از هر بار استفاده از دستگاه، دوشاخه دستگاه را از پریز برق جدا نمایید.
- از هرگونه تماس بین سطوح داغ دستگاه و پوست خود، به ویژه گوش، چشم، صورت، و گردن خودداری نمایید.
- این وسیله برای استفاده توسط افرادی با کم توانی جسمی، حسی یا ذهنی، یا افراد بی تجربه و ناآگاه (شامل کودکان) در نظر گرفته نشده است، مگر اینکه نظارت بر این افراد یا ارائه دستورالعمل استفاده ایمن از دستگاه و درک خطرات ناشی از آن، توسط سرپرست مسئول ایمنی آنها انجام گیرد. کودکان هرگز نبایستی با دستگاه بازی کنند.



- پیش از انبارش و نگهداری اجازه دهید دستگاه خنک شود.
- برای جلوگیری از آسیب به کابل برق، آن را به دور دستگاه نیچید. پیش از انبارش دستگاه از اینکه کابل برق دارای پیچ خوردگی و یا تا خوردگی نباشد اطمینان حاصل نمایید.
- هنگامی که دستگاه به پرز برق متصل می باشد، هرگز آن را بدون مراقبت رها نکنید.
- همیشه دستگاه را روی یک سطح صاف و پایدار، و مقاوم در برابر حرارت قرار دهید.
- هنگامی که دستگاه به پرز برق متصل می باشد، آن را از اجسام و مواد قابل اشتعال دور نگهدارید.
- هرگز زمانی که دستگاه داغ است، آن را با چیزی (مانند حوله یا لباس) نپوشانید.
- هرگز با دستان خیس از دستگاه استفاده نکنید.
- برس را تمیز و عاری از گرد و غبار نگهداری نمایید.
- هیچ قسمتی از دستگاه را با آب تمیز نکنید.
- برای جلوگیری از برق گرفتگی، هیچ چیزی را در دهانه های دستگاه وارد نکرده، و درون آن نیاندازید.
- خطر سوختگی، دستگاه را به خصوص حین استفاده و یا حین خنک شدن، دور از دسترس کودکان و خردسالان نگهداری نمایید.

#### نحوه استفاده از دستگاه

##### پیش از استفاده از دستگاه

۱. برس صاف کننده مو فقط برای موهای خشک استفاده شود. (از دستگاه برای موهای خیس یا مرطوب استفاده نکنید.)
۲. برخی از قسمت های دستگاه ممکن است داغ باشند، دستگاه را از دسته آن نگه دارید.
۳. برس را زیر شیر آب نشوید.
۴. به منظور جلوگیری از سوختگی های ناخواسته به برس دست نزنید، همچنین برس را به کف سر خیلی نزدیک نکنید.

##### دستور العمل نحوه استفاده از دستگاه

۱. دو شاخه دستگاه را به پرز برق متصل نمایید.
۲. کلید  را فشار دهید تا برس روشن شود. نشانگر کنار "ion" روشن می شود و برس شروع به گرم شدن میکند، میزان دمای 160°C به طور پیش فرض برای حرارت برس تعیین شده است.
۳. برای افزایش دمای تعیین شده کلید  را مجدد فشار دهید.
۴. مرحله ۳ را تکرار کنید تا دمای دلخواه خود را تنظیم نمایید.

۵. در طی گرم شدن، نشانگر کنار دمای انتخابی شما شروع به چشمک زدن می کند.
۶. زمانی که نشانگر ثابت ماند، برس آماده ی استفاده می باشد.
۷. به منظور تثبیت دمای دلخواه خود و قفل شدن آن کلید **⏻** را به مدت ۳ ثانیه فشار دهید. دومین نشانگر LED کنار علامت "قفل" روشن می شود.
۸. به منظور تغییر دما و یا خاموش کردن برس، کلید **⏻** را به مدت ۳ ثانیه فشار دهید تا قفل دستگاه باز شود.
۹. کلید **⏻** را فشار دهید تا برس خاموش شود.
۱۰. به محض روشن شدن دستگاه صدای بوق به گوش می رسد. دو صدای بوق کوتاه بیانگر روشن شدن دستگاه هستند و یک صدای بوق بلند بیانگر خاموش شدن دستگاه می باشد.
۱۱. در صورتیکه به مدت ۶۰ دقیقه از برس استفاده نشود، دستگاه به طور خودکار خاموش می شود.
۱۲. پس از خنک شدن کامل برس، آن را انبارش و نگهداری نمایید.

### نحوه صاف کردن مو

۱. پیش از استفاده موهای خود را به کمک شانه مرتب کنید.
۲. قسمتی از مو را جدا کنید و دستگاه برس را به فاصله ۳ سانتی متری از ریشه موها در زیر موهای جدا شده قرار دهید، طوریکه موها روی برس قرار گیرند و دندانهای برس باید رو به بالا باشد.
۳. دسته موی انتخابی را محکم نگه دارید و برس صاف کننده مو را با یک حرکت و به آرامی به طرف انتهای ساقه موها حرکت دهید.
۴. اجازه دهید موها به مدت ۳-۲ ثانیه خنک شوند.
۵. اکنون دستگاه را روی همان دسته از موها قرار دهید، طوریکه دندانهای برس به سمت پایین باشد و موها زیر آن قرار گیرد، برس صاف کننده مو را با یک حرکت و به آرامی به طرف انتهای ساقه موها حرکت دهید.
۶. تا دستیابی به نتیجه دلخواه مراحل ۲ تا ۵ را تکرار کنید.
۷. این فرآیند را برای مابقی موها تکرار کنید.
۸. به منظور حالت دادن موها بصورت مورب، هنگامیکه به انتهای ساقه موها رسیدید برس را به آرامی بچرخانید.
۹. با فشردن کلید **⏻** دستگاه را خاموش کنید.
۱۰. به منظور دستیابی به نتیجه مطلوب تر می توانید از اسپری محافظ حرارتی مو و اسپری های تثبیت کننده حالت مو استفاده کنید.

نوع مو	موی نازک و کم حجم	موی نازک رو به متوسط	موی متوسط ضخیم	موی متوسط رو به ضخیم
دمای انتخابی	160°C	180°C	200°C	220°C

## پس از استفاده از دستگاه

۱. دستگاه را خاموش کنید و دوشاخه را از پریز برق جدا نمایید.
۲. پس از خنک شدن دستگاه، موهای روی برس را جدا کنید و دستگاه را تمیز کنید.
۳. پس از خنک شدن دستگاه، آنرا در جای ایمن، خشک و تمیز انبارش و نگهداری نمایید.
۴. پس از استفاده، از کشیدن یا پیچیدن کابل خودداری کنید. برای جدا کردن دوشاخه از پریز برق همیشه دوشاخه را با دست نگه دارید.
۵. کابل را دور دستگاه نپیچید.
۶. دستگاه را در نزدیکی آب یا مواد قابل اشتعال انبارش و نگهداری نکنید.

## بازيافت



با توجه به قوانین اتحادیه اروپا، این دستگاه را نباید با زباله های خانگی دور بریزید. بلکه به مراکز بازیافت معتبر تحویل دهید.

## Disposal

This product is subject to the provisions of European Directive 2012/19/EC. The symbol showing a wheelie bin crossed through indicates that the product requires separate refuse collection in the European Union. This applies to the product and



all accessories marked with this symbol. Products identified with this symbol may not be discarded with normal household waste, but must be taken to a collection point for recycling electric and electronic appliances. Recycling helps to reduce the consumption of raw materials and protect the environment.

### Packaging

When disposing of the packaging, make sure you comply with the environmental regulations applicable in your country.

### To straighten your hair

1. Use a comb to detangle your hair before using.
2. Select one section of hair and place the brush underneath the hair strand with bristles facing upwards about 3cm away from your hair roots.
3. Hold the selected hair section taut while sliding down the brush slowly to your hair ends in a single motion.
4. Allow the section of hair to cool for 2-3 seconds.
5. Place the brush on top of the same hair with bristles facing downwards and slowly slide down to your hair ends in a single motion without stopping.
6. Repeat steps 2-5 as necessary until you achieve the desired appearance.
7. Repeat the process on the remaining strands of hair.
8. To bevel your hair, slightly turn in the brush as you reach the ends.
9. Turn off the appliance by pressing the On/Off button.
10. For best results, use with BBlunt Hot Shot Heat Protection Mist and Hot Shot Hold spray.

Hair Type	Fine, thin hair	Thin to Medium hair	Medium to Thick hair	Thick hair
Heat Selection	160°C	180°C	200°C	220°C

### AFTER USE

1. Turn off switch and disconnect the plug.
2. Clean the hair and dirty of the item after the appliance cools down.
3. Store the appliance in safe, dry, and clean place after it cools down.
4. Do not pull or strain cord after using. Always unplug the appliance by holding the plug.
5. Do not wrap the cord around the appliance.
6. Do not store the appliance near water or flammable materials.

- Never cover the appliance with anything (e.g towel or clothing) when it is hot.
- Never operate the appliance with wet hands.
- Keep the brush clean and free from dust and styling products.
- Do not clean any part of the brush with water.
- Do not drop or insert any object into the openings of the appliance to avoid electrical shocks.
- Burn hazard. Keep appliance out of reach from young children, particularly during use and cool down.

## HOW TO USE

### Before Use

1. Only use the brush on dry hair.
2. Some parts of the brush may be hot. Hold the appliance by its handle.
3. Do not wash the brush under running water.
4. Do not touch the bristles nor put the bristles too close to the scalp to avoid unintended burns.

### Operating Instructions

1. Connect the plug to a power supply socket.
2. Press the switch button to switch on the brush. The indicator light next to 'ion' will turn on and the brush will start heating to the default setting of 160°C.
3. Press the switch button again to increase the temperature setting.
4. Repeat step 3 till you reach your desired temperature setting.
5. The indicator light next to your desired temperature setting will keep flashing during heating.
6. Once the brush is ready to use, the indicator light will stop flashing and keep bright.
7. Long press the Switch button for 3 seconds to lock your desired temperature setting. The second LED indicator light next to the lock icon will turn on.
8. To change the temperature or switch off the brush, unlock by long pressing the switch button for 3 seconds.
9. Press the switch button to turn off the brush.
10. There is a buzzer sound upon switching on. Two short tones indicate power on and one long tone indicates power off.
11. After 60 minutes of inactivity, the brush will switch off automatically.
12. Store the brush after it cools down completely.



**Congratulations on the purchase of your new hair straightening brush. For a safe handling of the product and in order to get to know the entire scope of features:**

#### ELECTRIC PARAMETER

Model	Voltage	Frequency	Power rating
GHS 60	220-240 V~	50/60 Hz	50 W

#### IMPORTANT SAFETY INSTRUCTIONS

- WARNING:** Do not use this appliance near bathtubs, showers, basins, or other vessels containing water.
- If you are using the appliance in a bathroom, unplug and store away from water after usage.
  - Never immerse the unit in water or any other liquid.
  - If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
  - Do not use the appliance if it has fallen or if it appears to be damaged.
  - Do not leave the appliance unattended when it is plugged in or switched on.
  - Unplug the appliance immediately if you have problems when using it.
  - Do not use any accessories other than those recommended by BBlunt. Unplug the appliance after each use and before cleaning it.
  - Avoid any contact between the appliance's hot surfaces and your skin, in particular, your ears, eyes, face and neck.
  - This appliance is not intended for use by people (including children) with reduced physical, sensory or mental capabilities, or by persons who lack experience or knowledge, unless they are supervised or have been given instructions beforehand on the use of the appliance by a person responsible for their safety. Children should not play with the appliance.
  - Allow the appliance to cool before storing.
  - To prevent damage to the cord, do not wrap it around the appliance and ensure it is stored without twisting or folding it. When the appliance is connected to the power supply, never leave
  - Always place the appliance on a heat-resistant, stable flat surface.
  - Keep the appliance away from flammable objects and material when it is switched on.

# MIGEL



■ English

■ فارسی

Hair  
Straightening  
Brush

**GHS 60**